

SANITARY WASTE MANAGEMENT



Photo credit: Kentucky Best Management Practices for Construction Activities, 2005

Position portable toilets so that they are secure
and will not be tipped or knocked over.



Provided to you by Calcasieu Parish
Police Jury Environmental Department



USE: Prevent the introduction of wastes from construction site toilet facilities to storm drains or receiving waters.

DESIGN SPECIFICATIONS:

- Provide accessible restroom facilities on-site.
- Portable toilets should not be located near drainage facilities or receiving waters, nor should they be located in areas that will collect water.
- Do not discharge or bury wastewater at the construction site.
- Position portable toilets so that they are secure and will not be tipped or knocked over.
- Provide secondary containment pans under portable toilets, where possible.
- Provide tie-downs or stake downs for portable toilets in areas of high winds.
- Educate employees, subcontractors, and suppliers on locations of facilities.

MAINTENANCE:

- Inspect portable toilets for leaks, and repair or replace any leaks immediately.
- Maintain clean restroom facilities and empty waste regularly.
- Ensure that the sanitary/septic facilities are maintained in good working order and wastes are transported offsite by a licensed service.